

序号	名称	件号
1	十字槽螺钉	GA133095
2	油滤两端维特利接头	1-1/4"
3	维特利接头	165.1-75 6/168.3-75
4	主油泵回油单向阀	2"
5	维特利接头	219,1/8"-75 200A JIS75
6	气路用截止阀	3/8"
7	IGV本体	BTREIGV0012
8	Manual Valve	BUTTERFLY,[541T-G/OKM] DN150
9	SUCTION FILTER ELEMENT 进气过滤器滤芯	CJV415371
10	SUCTION FILTER ELEMENT 进气过滤器滤芯	CJV415372
11	BOCV阀体	CJV418906+CJV421749+CJV421750
12	放空阀	CJV418906+CJV421749+CJV421750
13	SV DRIVER	CJV421748
14	SV MOTOR	CJV421749
15	IGV执行器	CJV421749+CJV421750
16	铰链销	CJV421904
17	管连接器	CK915104
18	管连接器	CK915106
19	管连接器	CK915107
20	滑动轴承	CQ312917
21	FILTER Regulator element 调压阀滤芯	CQ51CNT020
22	软管接头	CQ51EJC006
23	KEY FOR MAIN OIL PUMP COUPLING	CQ71GEA002
24	润滑油压力调节阀	CQ71LUB004
25	振动传感器	CQ71SEN004
26	振动传感器探头	CQ71SEN005
27	1st stage diffuser shim	CQ80DFS001
28	2nd stage diffuser shim	CQ80DFS002
29	3rd stage diffuser shim	CQ80DFS003
30	TRE低速轴承	CQ80PBR001
31	TRE高速轴承 ( 高载荷 )	CQ80PBR008
32	前垫片	CQ81CLR015
33	前垫片	CQ81CLR016
34	橡胶密封条	CQ81CLR019
35	不锈钢密封条	CQ81CLR020
36	KEY FOR MAIN COUPLING	CQ81CPL001
37	主油泵联轴器	CQ81CPL002
38	油管	CQ81EJC003
39	oil pump adapter	CQ81GBX039
40	oil spray nozzle	CQ81GBX040
41	gear box	CQ81GBX069

42	法兰垫片	CQ81IGV013
43	1st stage inlet o-ring	CQ81ILT004
44	2nd stage inlet o-ring	CQ81ILT005
45	3rd stage inlet o-ring	CQ81ILT006
46	main oil pump	CQ81LUB031
47	3型垫片	CQ81LUB045
48	端盖垫片	CQ81LUB046
49	油封	CQ81LUB047
50	C型止动环	CQ81LUB048
51	1ST stage oil seal	CQ81RAB001
52	2nd stage oil seal	CQ81RAB001
53	3rd stage oil seal	CQ81RAB002
54	bull gear oil seal	CQ81RAB003
55	bull gear oil seal GASKET	CQ81RAB004
56	1st stage air seal	CQ81RAB005
57	2nd stage air seal	CQ81RAB005
58	3rd stage air seal	CQ81RAB006
59	air seal o-ring	CQ81RAB007
60	O型圈	CQ81SPR005
61	弹簧	CQ81SPR020
62	gasket of 4th side cover	CQ91GBX017
63	spacer washer	CR180224
64	lock nut	CR180302
65	pin	CR191424
66	THRUST BEARING	CR330500
67	大齿轮轴承	CR330503
68	bull gear bearing shim	CR330504
69	STRAIGHT PIN-SLOTTED	CR330926
70	维特利接头	CR531105
71	维特利接头	CR731105
72	排水用电磁阀	DG24V
73	膨胀节	DN150
74	Check Valve 止回阀	DN150 [JCQ91AIR037
75	辅助油泵回水过滤器	DN40
76	BOLTS	GA221244
77	六角头螺母	GA223063
78	六角头螺栓	GA323013
79	平垫圈	GD121006
80	法兰垫片	GV311106
81	法兰垫片	GV311107
82	法兰垫片	GV311112
83	法兰垫片	GV331106

84	法兰垫片	GV331107
85	法兰垫片	GV331112
86	法兰垫片	GV351015
87	法兰垫片	GV371009
88	法兰垫片	GV511010
89	O型圈	HA131225
90	O型圈	HA131228
91	卡箍	HA311001
92	橡胶接头卡箍	HA311015
93	橡胶接头	HA411015
94	Lubricating Oil 齿轮箱润滑油	HA811016
95	专用润滑油	HA811016
96	伺服型IGV/BV减速机	I=1/158.12 CJV421750
97	O型圈	JC812023
98	O型圈	JC812038
99	o-ring	JC816027
100	main oil pump adapter o-ring	JC826015
101	电流变送器	JCQ200016
102	断路器	JCQ200018
103	接触器	JCQ200021
104	热继电器	JCQ200022
105	继电器插座	JCQ200028
106	转换开关	JCQ200034
107	开关电源	JCQ200038
108	三孔插座	JCQ200058
109	人机界面	JCQ200099
110	断路器	JCQ200114
111	断路器	JCQ200116
112	CPU	JCQ200166
113	CPU	JCQ200166
114	数字量输入模块	JCQ200167
115	数字量输出模块	JCQ200168
116	热电阻输入模块	JCQ200169
117	模拟量模块	JCQ200170
118	模拟量模块	JCQ200171
119	通讯端子排	JCQ200172
120	功率继电器	JCQ200210
121	继电器插座	JCQ200211
122	功率继电器	JCQ200231
123	功率继电器	JCQ200245
124	功率继电器	JCQ200246
125	功率继电器	JCQ200248

126	操作面板	JCQ200266
127	变压器	JCQ200274
128	急停按钮	JCQ200282
129	选择开关	JCQ200325
130	超级电容	JCQ200431
131	网关	JCQ200432
132	进气管	JCQ81AIR006
133	进气管	JCQ81AIR010
134	维特利接头	JCQ81AIR040
135	AUTO Muffler 放空消音器滤芯	JCQ81AIR082
136	消音器	JCQ81AIR082
137	前端盖垫片	JCQ81CLR053
138	前端盖垫片	JCQ81CLR054
139	后端盖垫片	JCQ81CLR055
140	后端盖垫片	JCQ81CLR056
141	空气冷却器	JCQ81CLR061A/JCQ81CLR062A
142	MAIN COUPLING	JCQ81CPL032
143	叠片	JCQ81CPL043
144	衬套	JCQ81CPL049
145	螺母	JCQ81CPL049
146	螺栓	JCQ81CPL049
147	自动排水阀	JCQ81DRN006
148	油雾分离器芯	JCQ81EJC002
149	Breather Element 呼吸器滤芯/排气洁净器	JCQ81EJC002/[AMV15-20/SMC]
150	电磁阀	JCQ81EJC016
151	垫片	JCQ81LUB024
152	垫片	JCQ81LUB025
153	金属软管	JCQ81LUB054
154	维特利接头	JCQ81LUB076
155	垫片	JCQ81LUB077
156	回程端盖垫片	JCQ81LUB079
157	进口端盖垫片	JCQ81LUB080
158	OIL FILTER ELEMENT 油过滤器滤芯	JCQ81LUB092
159	润滑油管路用过滤器	JCQ81LUB092
160	油滤滤芯	JCQ81LUB092
161	镀锌头	JCQ81LUB123
162	辅助油泵	JCQ81LUB145
163	油冷却器	JCQ81LUB160
164	负压表	JCQ81OTK012
165	压力传感器	JCQ81SEN002
166	压力传感器	JCQ81SEN003
167	温度计	JCQ81SEN004

168	油压表	JCQ81SEN005 0-50PSI
169	油位开关	JCQ81SEN006
170	温度传感器	JCQ81SEN128
171	bearing	JCQ81SPR017
172	O型圈	JCQ81SPR018
173	油封	JCQ81SPR019
174	密封垫纸	JCQ81SPR020
175	维特利接头	JCQ91AIR006
176	4th side cover	JCQ91GBX300
177	球轴承	JCQ91IGV017
178	叶轮导流器保养包	JS80MTE002
179	叶轮导流器清洗包M3	JS80MTE002
180	1级进气管路保养包	JS80MTE005
181	进气管维修包	JS80MTE005
182	齿轮箱保养包	JS80MTE009
183	叶轮间隙维修包	JS80MTE012
184	迷宫密封包	JS80MTE017
185	油冷保养包	JS80MTE106
186	空冷保养包	JS80MTE133
187	冷却器维修包M3	JS80MTE133
188	排气止回阀保养包	JS80MTE305
189	联轴器维修包	JS80MTE403
190	油管路保养包	JS80MTE503
191	油管路维修副包	JS80MTE505
192	辅助油泵回水截止阀	KITZ 1/4"
193	1st stage impeller	KTRE0017001
194	2nd stage impeller	KTRE0017002
195	3rd stage impeller	KTRE0017003
196	短直管	M1600-150 C
197	油冷换热器接头	NH100085-150
198	维特利接头(回油箱)	NH100085-400
199	1st stage diffuser	SF80DFS001
200	2nd stage diffuser	SF80DFS002
201	3rd stage diffuser	SF80DFS003
202	1st stage inlet	SF80ILT001
203	2nd stage inlet	SF80ILT002
204	3rd stage inlet	SF80ILT003
205	LED灯组 LED Group	包含在操作面板
206	L-CKE320# 蜗轮蜗杆齿轮油	伺服型IGV/BV减速机润滑油